

V1.2

OWNER'S
MANUAL



CAR MEDIA SYSTEMS



VN720 VO-P6C

VISION
NAVICEIVER

INTRODUCTION

Always follow the instructions in this manual before using the device. Please keep this manual easily accessible in the vehicle for future reference.

Features

- iGo Primo, 3D navigation software with TMC on 8GB SD card, 46 countries including Turkey with Points of Interests display and search function, 3D building views, TTS voice output, warnings, over 25 system and prompt languages Latest Map Guarantee (30 days) after activation via www.naviextras.com.
- High-resolution 17.8 cm (7") LCD touchscreen display with 800 x 480 pixels
- Advanced i20 operating system based on Microsoft Windows CE 6
- MTK Dual Core Cortex A9+A11 800 MHz CPU, 256MB DDR3 RAM, 256MB NAND Flash RAM
- Audio amplifier with 4 x 50 Watts max.
- Pre-amplifier outputs Subwoofer/Center/2 x Front/2 x Rear
- DSP-Audioprocessor with 10-Band-Equalizer and 5.1 Surround-Sound
- Bluetooth™ hands free, phone book synchronization and A2DP audio streaming
- Media playback (MP3/WMA/MPEG4/MPEG1/2/WMV/AVI/DivX/FLAC etc.), supports FullHD 1080p (1920 x 1080) playback
- Quick-Boot (approx. 10 seconds)
- Support ACC Logic: the device can be operated up to 30 minutes without ignition
- DVD-Player (DVD, DVD-R/RW, DVD+R/RW, VCD, CD, CD-Text, CD-R/RW, MP3)
- Radio AM/FM with RDS function (supports Europe, North America, Asia)
- Virtual Disk to convert audio CDs into MP3 format
- E-LINK mirror function with compatible Android smart phones
- Quick Charge USB function with up to 2.1A charge current
- Voice control (except navigation)
- Custom design function (wallpaper, startup logo, menu), several design themes (skins) for customizing the user interface
- Individually adjustable pre-channel volume for each application
- File manager with an open file structure, photo slide show
- MicroSD card slot and USB port with copy function
- Integration of external applications (Compatible with Windows CE 6)
- Date/time function, 12/24 hrs. display
- 3 x Audio/Video output
- 2 x Audio/Video input
- Front and rear camera inputs
- Supports original factory AUX-In and USB-Port
- Supports 2D-/3D navigation maps with TMCpro function
- Supports external TV or radio receivers (DVB-T, DAB, etc.)
- Supports iPod / iPhone™ with ID3 tag display via USB (compatible with iPhone 5/6), with media library, cover display and ID3 Tag display
- Supports original hands-free microphone*
- Supports original multi-function steering wheel
- Supports original rear view camera incl. guiding lines*
- Supports original multi-function display (MFA)-, optical parking system (OPS)- and A/C display (Climatronic)*
- Vehicle settings such as illumination, A/C profile, central locking system, windshield wipers, parking assistant and tire pressure monitoring system can be adjusted or controlled by the device.

* depending on vehicle

Compatibility (Status September 2016)

Volkswagen Polo 6C (since 04/2014) with original radio „Composition Touch“ or „Composition Colour“.

Not compatible with original radio „Composition Media“ and „Discover Media“

Certain vehicle features and functions are depending on the equipment.



IMPORTANT NOTE FOR YOUR VEHICLE'S SERVICE STATION

After installation of the ESX Naviceiver inside the vehicle, the device is not recognized as the original radio and causes an error message in the fault memory of the vehicle (depending on the vehicle, for example „Infotainment CAN, no communication“). This error message is normal in connection with our ESX device and can not be deleted.

Windows is a registered trademark of Microsoft Corporation in the United States and other countries. iPod and iPhone are trademarks of Apple Inc.. The Bluetooth word mark is registered trademark owned by Bluetooth SIG, Inc. Other trademarks, trade names or brands are the property of their respective owners.

Safety Information	4
Basic functions	6
Operating elements	6
Main menu	7
Navigation	8
Multimedia player	9
Radio	11
Car Information	14
Application	16
– <i>Vehicle Setting</i>	17
– <i>Bluetooth™</i>	18
– <i>DVD (DVD/CD-Player)</i>	21
– <i>LinkPod</i>	22
– <i>AV/TV</i>	23
– <i>Quick Charge</i>	23
– <i>A2DP</i>	24
– <i>Files</i>	25
– <i>Virtual Disk</i>	26
– <i>E-Link</i>	28
– <i>Option</i>	30
– <i>Audio</i>	36
Custom settings	39
Menu assignments	39
Wallpaper	40
Start logo	41
Additional functions	42
Infrared remote control	42
Multifunction steering wheel	43
Multifunction display	43
Limited media playback	43
Optional rearview camera	44
Optical parking system (OPS)	44
Troubleshooting	46
General notes	50

SAFETY INFORMATION

- In general, the assembly and installation of the device must be performed by a trained and technically skilled specialists, as the installation and connection of the device requires complex knowledge.
- This device is only suitable for the operation in a vehicle with an on-board voltage of 12 volts, negative ground.
- Improper installation or use may void the warranty.
- Note any time the traffic regulations of the country in which the device is operated.
- Please ensure, that with the engine turned off the vehicle's battery does not discharge fully. The device is another electrical consumer which must be operated with the engine running, other-wise the vehicle's battery will be discharged and the vehicle can not be started.
- Set the volume of the device only as loud, that you are still be able to hear warning signals (e.g. police sirens) and traffic noise inside the vehicle.
- Operate the device as driver only if it's absolutely necessary and in the driving safety is not compromised. The same stands for looking at the screen. If necessary, better park your vehicle at a safe and appropriate location.
- The traffic rules of the EU prohibit to view moving pictures or movies while driving, if the screen of the device is installed within sight of the driver, as he may be distracted. View the screen as driver only for the navigation function, and then only briefly that you will not be distracted. Note at any time the local traffic regulations. In an accident, regress claims could be made by the car insurance company.
- This device is not a substitute for your personal judgment or perception. All suggested routes from the navigation system should never be taken as a reason to disregard the local traffic rules. Your personal assessment of traffic or your knowledge of safe driving practices is paramount. Always match your driving with the current traffic situation.
- Do not follow the suggested routes, if the navigation system instructs you to take an unsafe or illegal way, puts you in an unsafe situation, or directs you into an area which you consider unsafe.
- If problems occur while driving, park the vehicle in a safe and appropriate place to continue before you operate.

- The device supports only DVD/CD standard disk size of diameter with 12 cm. Do not attempt to insert disks with a different size or any other object into the disk slot. Be sure to load only one disk at the same time.
- Please use only the included original accessories. Ensure a sufficient mounting of the device by using the included installation accessories, as in the event of an accident enormous accelerations may occur. Poorly installed devices and equipment in accidents could represent a severe risk to the driver and the other passengers of the vehicle.
- Note under all circumstances the regulations and advice of the vehicle manufacturer and do not make any modifications to the vehicle, which could interfere with safe driving. Please treat all parts of the device and the components of your vehicle always with caution.
- Please avoid short circuits and make sure that no metal objects can get inside the device. Also make sure that all connections are properly connected and avoid the interchanging of the polarity of all connections. Complete the installation only while the ignition is turned off.
- In the event of a defect or malfunction, do not attempt to repair it by yourself or open the device, this is dangerous and could cause injury or damage to the equipment or vehicle. A repair should be done by trained and authorized personnel only. The device uses a Class 1 laser to read the disk. Eye contact with a laser is very dangerous to the human eye.
- If you connect an external device, you should first read the instruction manual of the external device and make sure that it is compatible. Avoid connecting an incompatible external device.
- If you install external applications onto the operating system of the device or operate files, make sure that they are „virus free“ and compatible with Windows CE 6. Otherwise there is a risk that the operating system no longer works properly and must be reinstalled.
- Do not damage or scratch the screen with sharp objects. Do not operate the screen with hard objects.
- Please refer the notes in chapter GENERAL NOTES on page 50



This symbol indicates important information and instructions in this manual, which serve to improve traffic safety and operability of the device.

▶ OPERATING ELEMENTS



1. Turn the display on / off.
2. Start or pause the media playback.
3. Slot for CD/DVD disks (Ø 12 cm).
4. Eject the inserted CD/DVD.
5. Open the DVD/CD player menu.
6. Internal Bluetooth microphone
7. Open the main menu.
8. Open the navigation system.
9. Skip to the next track/title/station/chapter.
10. Open the radio mode (short push) or open the DAB+ radio (push and hold, if connected).
11. Skip to the previous track/title/station/chapter.
12. Open the multimedia player.
13. Activation of the voice control (short push) or to activate or deactivate the mute function (push and hold)
14. Open the phone mode.
15. Reset button.
16. Mute (short push) or the device switches to stand-by (push and hold - no audio, display darkens, running navigation stops, Bluetooth connection interrupts).
Volume controller (rotate).
17. MicroSD card slot.
18. Controller knob for selecting or switching in the user menus.
Push knob to open the audio settings.

MAIN MENU

After power on, the device starts with the main menu. By pressing the „MENU“ button on the device, you can always get to the main menu too.



1. Depending on the selected design theme (Skin), the current date and time will be displayed here.
2. Depending on the selected design theme (Skin), the current exterior temperature in ° Celsius will be displayed here.
3. The four function icons are (depending on the skin) is highlighted in white and thus activated when the corresponding function is in use, such as „Bluetooth connection“, „CD / DVD in the drive“, „iPod connection“ or „USB connection“.
4. The main menu displays five to eight key panels, which open the selected application or lead to the regarding sub menu.
5. In chapter „CUSTOM SETTINGS“, section „Menu assignments“ (Pg. 39) shows how to customize and arrange the key panels.
6. Depending on the selected design theme (Skin), the currently air-conditioning settings for the driver and co-driver will be displayed separately for the (depending on model).



Basically, the device can operate several applications simultaneously. But if too many extensive applications running at the same time, it can slow the operation (not responding to your input) or even crash the system.


BASIC FUNCTIONS

⚡ NAVIGATION

Open the navigation application by tapping „Navigator“ in the main menu or by pressing the „NAVI“ button on the device.

Please refer to the separate manual for the navigation software.


The device provides the ability to use any navigation software (Windows CE 6.0 compatible). Patch the navigation software (on MicroSD card) with the device as follows:




Tap on „Option“.



Tap on „System“.



Tap on „Browse“.



Tap on „SD“ and then select the software on the MicroSD card with a double click. This navigation software is starting as soon as you tap on „Navigation“ in the main or push the „NAVI“ buttons on the device.

Note: If you have accidentally changed the path and want to use the original ESX iGO software, the path must be always „Storage Card\NaviOne\Navione.exe“.




The unit receives GPS satellite signals automatically. In poor weather conditions or for example while passing a tunnel, these signals may be disturbed. This could lead to a malfunction of the GPS positioning.

MULTIMEDIA PLAYER

Open the multimedia player (source selection via USB or SD) by tapping „Multimedia“ in the main menu or by pressing the „MUSIC“ button on the device. Refer to page 21 for CD Audio playback.



1. Tap here to enter the main menu without interrupting the playback of the current title.
2. Current time.
3. Source information and track number.
4. Tap here to exit the application, the playback will be interrupted.
5. ID3-Tag album cover of the current audio file.
6. Title/artist/album information.
7. Progress bar of the currently playing audio file. With the displacement of the knob you can jump to another point in the track.
8. Elapsed time and the total time of the track.
9. Tap here to open folder list or to change the play mode (music or video).
10. Playback controls for audio player
 - Play previous track
 - Start or pause playback
 - Play next track
11. Repeat function
 - Repeat all titles
 - Repeat only the current folder
 - Repeat single track
12. Tap here to start random playback



FOLDER PLAYBACK

Tap on the folder icon in the multimedia menu on the bottom left (see page 9, #9) and the currently playing folder appears. Now you can scroll through the list and select another song by tapping directly or with „go back“ to a higher directory level to open another folder. Tap on the desired file and its playback starts immediately. Close this menu on the top left with „X“ to go back to the multimedia player menu.



REPEAT FUNCTION

Symbol 1: When the last song has been played within a folder, the playback will continue to the next folder. After the last song, playback starts again from the beginning.


Symbol 2: The current folder is repeated

Symbol 3: A single track is repeated



RANDOM PLAY

To shuffle all tracks or all tracks within a folder (if a folder was previously selected).



MOVIE PLAYBACK

Select the folder icon and then „Movie“ on the bottom right. Now all movie files of the connected media are displayed. Are these located in several folders, you can switch to a different directory with „go back“ like in the music player. The „Repeat Function“ and „Random Play“ have the same function as in the music player. Tap during the full screen playback shortly at any point on the screen to open playback options.


Note: The playback of a movie file is only possible if the hand brake is closed.



If the playback does not start (a USB stick can not be detected or the source selection is not working as expected) close the multimedia player with „X“ top right (page 9, # 4) and restart it.


 **RADIO**

Open the radio application by tapping „Radio“ in the main menu or by pressing the „RADIO“ button on the device.



1. Tap here to enter the main menu without interrupting the radio playback.
2. Current time.
3. Displays the current frequency band and the current station frequency, tap here for directly quick tuning.
4. PTY category of the current station.
5. Signal strength of the current station.
6. Tap here to exit the application, the playback will be interrupted.
7. RDS name of the current station.
8. Fine adjustment of the frequency, Arrow left for downward, arrow right upwards.
9. RDS (AF, TA, PTY) features.
10. RDS information of the current station.
11. With the arrows you can quick-start the search for a station from the current frequency up or down.
12. Station presets.
13. Press „Scan“ about 2 seconds to start the automatic radio station search. Then up to 32 currently available stations will be stored in all four the station presets.
Note: All previously stored stations will be erased and overwrite.
A quick tap on the icon enables a jump to the next available station.
14. Tap here to the open the different preset pages, with 8 station presets each.
15. Tap here to open the settings.

Settings and station presets



Tap on the „gear“ icon to open the settings and then:

„Rename Station“ to rename the current radio station.

„Delete Station“ to delete the current radio station from the presets.

„Delete All Stations“ to delete all radio stations from the presets.

„Local Setting“ to open the settings for the local radio frequency standards.

„Audio“ to open the audio settings. Refer to the instructions in section „Audio“ in the „APPS“ menu.

REG OFF and REG ON switches the RDS function „REGIONAL“ on or off. If the menu shows „REG OFF“, the regional function is activated.

„EON ON“ or „EON OFF“ to switch the “Enhanced Other Networks (EON)” on or off. This feature allows you to receive traffic information (TA), even if the currently selected channel does not have a TA program.

„Mono“, to switch off the „stereo“-mode manually on weak radio stations.



Rename Station:

Tap on the white input box to change the radio station name by using the screen keyboard.

Tap on „Name as freq.“ to set the frequency as radio station name.

Confirm your entry with „OK“ or tap „Cancel“ to exit the menu without changes.



Local Setting:

Choose e.g. EUROPE from the list of local radio frequency standards.

Confirm your entry with „OK“ or tap „Cancel“ to exit the menu without changes.

After you change the settings, restart the radio application.

RDS functions

This device supports RDS (Radio Data System) in the frequency range 87.5 - 107.9 MHz FM. The following RDS functions are only available if they are supported by the selected radio station.




AF (Alternative Frequency)

The AF function enables the automatic switching of the receiving frequency when leaving the reception range of a transmitter. The device then checks the reception quality and automatically switches to a different frequency, when the same program in another reception area is also available. This is done automatically, without the user is notice anything.



TA (Traffic Announcement)

The TA function enables the interruption of the media playback (audio player, CD, DVD, etc.) for traffic announcements. After the announcement, the previous media playback starts again.



PTY (Program Type)


The PTY function is a classification of radio stations in different categories. Each program of a RDS radio station is classified categorically.

After you have selected a category, the unit automatically searches for the next matching radio station in this category. During the „Automatic scan“ only programs will be found, that match to the chosen category. If you no longer want this function, select the category „None“.

BASIC FUNCTIONS


Car Information

The app „Car Info.“ shows various important vehicle information. The menu consists of three sub-menus:



To enter one of the submenus below tap the desired panels.


Driving data



In the submenu „Driving data“ the already traveled kilometers will be displayed such as the average speed, maximum speed and the total travel time as well as the vehicle’s fuel consumption in liters per 100 kilometers.

Chose with the arrows top left and right between „Since start“- „Since refueling“- and „Long-term“-display.


Convenience consumers



In the submenu „Conv.consumers“ shows how the operation of the air conditioning has an effect on the vehicle’s fuel consumption in liters per 100 kilometers.


IMPORTANT NOTE: The “Car Info.” menu is only available in the Skin “ESX POLO” (See pg. 30). Other, subsequently installed skins may not support this feature.

Vehicle status




In the submenu „Vehicle status“ you can to switch between „Vehicle Status“ and „Tire Pressure Monitoring System“ (if present) by using the arrows on top left and right.


Both displays show vehicle-relevant information is if action is needed.



Here you can see the sub-menu „Tire-pressure Monitoring System“. Press „SET“ after you have the tire pressure of all four wheels checked and adjusted correctly.



Tap on „Start-Stop“ to open the Start-Stop menu.




Here you find information about the status of the „start-stop system“ as well as information about the vehicle.

APPS

Open the application menu by tapping on „Apps“ in the main menu.

The device offers a variety of applications that can be used as described below. Some of these functions require the appropriate accessories.




1. Tap here to switch off the display. To switch on the display again, tap onto the screen.
2. Tap here to open the LinkPod menu, if an iPod/iPhone is connected with the device.
3. Tap here to open the AV/TV menu.
4. Tap here to open menu „Vehicle Setting“.
5. Tap here to go back to the main menu.
6. Tap here to open the Bluetooth™ menu.
7. Tap here to open the VirtualDisk menu.
8. Tap here to start the A2DP audio streaming.
9. Tap here to open the option menu.
10. Tap here to open the E-Link menu.
11. Tap here to open the Quick Charge menu.
12. Tap here to open the file manager.

In Chapter „CUSTOM SETTINGS“, section „Menu assignments“ (Pg. 39) shows how to customize and arrange the key panels.

 **VEHICLE SETTING**


Open the vehicle setting menu by tapping on „Vehicle Setting“ in the main menu. The appearance is based on the original menu.




NOTE: The „Vehicle Setting“ can only be selected when the ignition is on.

Certain menu options only work if permitted by the vehicle equipment or if they exists at all (e.g. ambient light).

The selected function is not always working the same way than the original system, e.g. the ambient light changes only when all doors are closed.



Scroll through the various menu options and tap the desired function to display its sub-menu.



In the corresponding sub-menus different values can be adjusted or a function can be turned on or off.

However, the function is always depending on the vehicle equipment.

IMPORTANT NOTE: The “Vehicle Setting” menu is only available in the Skin “ESX POLO” (See pg. 30). Other, subsequently installed skins may not support this feature.

▶ BLUETOOTH™

Open the Bluetooth™ application by tapping „Bluetooth™“ in the main menu or by pressing the „PHONE“ button on the device.




PAIRING

At first pair the devices, if necessary refer to the manual of your mobile phone. Open the „Settings“ menu on your mobile phone and open the Bluetooth settings.


Turn on Bluetooth and then search for compatible devices. The Bluetooth name of the device will be displayed.

Select your device from the device list in the phone and enter the PIN code **1234**. Alternatively, you can also search your mobile phone under „Devices“ and connect to the device. Once you have connected your phone to the device, the pairing starts automatically as soon as the two devices are within range. Leave Bluetooth activated on the mobile phone. If a mobile phone has already been added to the list of Bluetooth devices, you can also manually pair the devices. The range for a satisfactory connection is about 10 m.

DISCONNECT



To disconnect the two Bluetooth devices, tap on „Devices“.



Choose the mobile phone from the list and tap „Disconnect“ or quit the Bluetooth connection on your phone.


Alternatively, the phone can also be deleted from the list, but after that, the automatic pairing is disabled and the mobile phone must be re-paired with the device. To delete the mobile phone from the list, select the name and press „Delete“. This is only possible if the devices are not currently paired.




The paired mobile phone has always priority and a phone call mutes always the currently playback of media (navigation, radio, audio, DVD, etc.). This applies both for incoming calls as well as outgoing calls.

CONTACTS AND CALL HISTORY


Once your mobile phone has been connected via Bluetooth to the device, the synchronization of your contacts and call history starts automatically.




Tap on „Contacts“.



Tap on a name to start a phone call.



Tap on the white search field to search for a contact, by typing its name on the screen keyboard.



Tap on „History“.



Tap on „Missed“ to display the missed phone calls.



Tap on „Received“ to display the already received phone calls.

BASIC FUNCTIONS




Tap on „Dialled“ to display the already transacted phone calls.



To synchronize your contacts and call history tap on „Sync. Now“.

KEYPAD



Tap on „Keypad“ to enter phone numbers manually. Then enter the desired number and then tap the green phone icon to start dialing. Tap the red phone icon to end the phone call.

You can dial with the paired mobile phone, but this is not recommended while driving and may be illegal in your country.

 **DVD** (DVD/CD-Player)

The DVD player supports the following formats: DVD, DVD-R/RW, DVD+R/RW, VCD, CD, CD-R/RW, MP3. Open the DVD application by tapping „DVD“ in the main menu or by pressing the „DVD“ button on the device.


Tap during DVD playback on any spot on the display to open the DVD menu. When you playback a CD or MP3-CD, the user interface is different.



- | | |
|---|-------------------------------------|
| 1. Shuffle | 8. Play / Pause |
| 2. Repeat (chapter, track, all tracks, Off) | 9. Next chapter |
| 3. Video settings | 10. Title menu of the DVD |
| 4. Eject inserted disk | 11. Change language (if available) |
| 5. Minimize, playback resumes | 12. Change subtitles (if available) |
| 6. End DVD Playback | 13. DVD menu of the DVD |
| 7. Previous chapter | |


BASIC FUNCTIONS

LinkPod (optional)




Connect your iPod™ or iPhone™ via USB with the ESX device. When the iPod™ icon is highlighted in white (top next to the time display), the connection is active.


The battery charging function is carried out when the unit is turned on. For older iPod™ models, it may happen that these are not recognized after the power is turned off. Pinch in this case, the iPod™ off and back on.



The user interface is modeled like the user interface of the iPod™. You get access to the iPod™ its contents and play-lists through the lower control panels. By tapping „MENU“ you can make the desired playback settings such as „Shuffle“ or „Repeat“.



By tapping on „Media Library“, the library opens. There you can select the desired criteria (artist, playlist, album, genre, etc.) for the playback.




With „Audio“ and „Podcast“, you can access the desired media type of the iPod™.



Please avoid disconnecting the iPod/iPhone™ during operation. This could cause a system crash.


AV/TV (optional)



The AV/TV menu offers the possibility to playback a audio or source.

Please refer for operation, installation and functionality to the instruction manual of the connected device.


Note: AV is not available when the external DAB receiver „VNA-TM-DAB“ from ESX is used.



The connections are as follows:

- AV = Cable AV 1 (3 x RCA)
- AV2 = Cable AV2/TV (3 x RCA)
- AV3 = Cable AV3/AUX (3 x RCA)
- AUX = Factory AUX connection
(depending on vehicle/features)
- Front Cam = Cable „FRONT-CCD-IN“
- Rear Cam = Cable „CCD-CVBS-IN“

QUICK CHARGE (optional)



With „Quick Charge“ you can quick charge your mobile device via USB.



Tap on „Enable Quick Charge“ to activate the quick charge function. To disable the feature again, tap on „Disable Quick Charge“ at the same place position.


Please note that the USB data function is deactivated when the USB connection is used for the quick charging.

The ESX device provides in „Quick Charge“ function a charging current of 1A - 2.1A (depending on the connected equipment).

Note: Please note that the „Quick Charge“ function only works with USB port 1.

BASIC FUNCTIONS

A2DP (optional)



Once a Bluetooth device is (mobile phone, computer, tablet) coupled via Bluetooth, which works with the streaming A2DP standard, there is the possibility, to playback audio stream over the ESX device. Connect this device as described on page 15 and select a music source A2DP under Apps.




If the message „A2DP is not connected“ appears, your BT device it is not connected or the audio playback is not (yet) enabled. Check the Bluetooth device and if the appropriate settings for the audio streaming are correct. Then, disconnect the device and connect it again. If the message „A2DP is not connected“ appears again, the Bluetooth device does not support the A2DP standard.



Start playback of the desired music on the Bluetooth device or with the keypad „>||“ on the touch screen. If you play a playlist, you can use also the keypad „|<<“ and „>>|“ on the touch screen, respectively the „SEEK + / SEEK“ buttons or the rotary control on the ESX device to select the desired title.


Files




With the file manager, it is possible to manage and open computer specific file formats. The system supports the following file formats:

- Photo: BMP, JPEG, GIF, PNG
- Video: MPEG (*.mpg, *.mpeg), AVI, RM (*.rm, *.rmvb), WMV, MP4 (*.mp4, *.mov), MKV (*.mkv)
- Audio: MP3, WMA, WAV, FLAC, AAC, Monkey Audio (*.ape)


Tap once to highlight a particular file. Tap twice (double-click) to open the desired file.



Tap on the desired storage location to display the available and compatible files.




Tap on the upper bar to display the desired file category. Then the file browser shows only the chosen files. Choose for example „Photo“, then only all available photos including a preview will be displayed.




Tap on „Option“ to perform file operations, such as deleting or copying files.

With the copy function, it is possible to copy files to another location or to another disk.

BASIC FUNCTIONS



Once you have open an image file, you can start a slideshow of all the pictures stored in the directory. Tap on the image and the playback options are displayed.



Tap on „Info“ to view the memory information of each storage locations.

Here you can view the file categories and the used disk space on the selected storage location.

The usage is displayed in percent and in kilobytes/megabytes/gigabytes.

VIRTUAL DISK (optional)



HOW TO CONVERT

The Virtual Disk feature allows you to convert audio CDs into MP3 format. For this purpose it is always necessary that a USB stick is connected.

How to read a CD:

- Open Virtual Disk under APPS.
- Connect a USB stick and insert a CD
- The playback of the inserted CD will start automatically
- Select a disc number on which position the the CD should be ripped and stored.


Note: If „Disk Ripped“ is displayed in the center of the screen the CD songs are already available - they will be overwritten as soon as you select „Start Rip“. If „Disk No Rip“ appears under a selected disc number, no ripped CD is available.

Select „Rip Start“. The progress bar shows the current progress of currently ripping title and all the total title numbers (e.g. 2 of 11).

Select „Rip Stop“ to cancel the process. All previously ripped songs remain on the drive.



Note: When using multiple USB sticks, the stick with the desired RIPS must have been always connected first! If you can not access the RIPS, remove all USB sticks and connect the appropriate stick via USB. If you connect a USB Stick with contained CD RIPS while is Virtual Disk opened, they will not appear immediately. After recognizing the sticks (audible beep) tap on the disc number 1 - 10 again.



If the message „Rip Fail“ appears possibly the CD has not been recognized/not yet ripped read or it is faulty/illegible/scratched.

After a successful completion, „Disk Ripped“ appears.

From now on this album is stored under the selected button e.g. „Disk 1“ and will be always playable, as long as the USB stick is connected. You can store a total of 10 CDs in this way.



PLAYBACK

Select to „Rip Play“ to start in the play mode of the archive.

The playback of disc 1 automatically begins.



Select the desired disc 1-10. If there are no songs stored, the playlist is empty.

You can switch through the titles with |<<, >>|, or with the right rotary control of the device, Seek +, SEEK or the steering wheel remote control by switch.

The tracks can also be selected directly in the black title list by tapping on the titles, where you can also scroll through the title list.

If you want to rip more CDs, select „Rip“ on the top right corner.



The ripped and stored titles on the USB stick songs are also available in the regular audio player. They are titled there including the CD-number, e.g. „Cd1_Track08“. Physically the data is stored in a folder named „RIP“ on the USB stick.

To delete a ripped CD on the USB drive, use the file manager (under APPS> files).

BASIC FUNCTIONS

E-Link (optional, only for Android devices)


Note: Please ensure that for this function a permanent Bluetooth™ connection for the E-Link mode audio signal is required. Please refer to the section Bluetooth™ on page 15th



Start „E-Link“ under „Apps“ and follow the onscreen instructions.

By tapping on „?“ you get information on how to activate the so-called USB debug mode. Please note that the procedure for any Android device may vary.


Connect your Android device via USB to the ESX Naviceiver and tap on „Detect Phone“.



The first time you connect to an Android device, the device will automatically install the „Drive Mode“ app and a license file on your smart phone via the Internet (3G or WiFi)


Activate therefore your internet data connection. This is only necessary on the first interconnection.

„Exit“ closes the application.




After the successful coupling the „Drive Mode“ app starts automatically.

The App menu contains initially the basic applications on your Android device which can be accessed via the „Drive Mode“ app, such as Driver Mode (voice control), Music (audio player), Navigation, Telephone and Message (SMS application).




It's possible to modify the app menu according to your requirements, e.g. to embed extra applications. Click on a free App field (marked with a +).

If you wipe the app menu to the left, another app menu appears.




Under „Choose Application“ you can select the desired application.



By tapping on the transparent „>“ arrow on the bottom left, a further window opens in the lower third of the screen.

There you find more options such as „Back“, „Home“, „Settings“ or „Forward“.



Under „Settings“ you can select:

„If open TTS“: Selection of the internet search engine for Voice Control

„Audio back ...“: After 5 seconds of inactivity jumps the application will automatically return to the „Drive Mode“ -Appmenü.

„Audio open ...“: Automatic answer for incoming calls.



Note: In order to increase road safety, every time you start the „E-Link“ feature, the „Drive Mode“ app will be installed/ or started on your smart phone.

BASIC FUNCTIONS

Option

You can open the option menu by tapping on „Options“ in the „Apps“ menu.


Language settings




Tap on „Skin“.



Select the desired language. Tap on „Apply“.




Tap on „Skin“.




Tap on the menu „Skins“ and select the desired design theme (skin). Tap on „Apply“.


Date/Time




Tap on „Date/Time“.




Select the desired time zone.



Set the current date.




Set the current time.



Tap on the check box right to set on daylight saving time.

Tap on the check box left to set the time format to 12-hours (AM / PM).




Tap on „Apply“.

Display




Tap on „Display“.



Set the desired brightness level for the display (only with vehicle headlights on).


BASIC FUNCTIONS




The check box „CCD Camera“, enables the optional rear view camera function. As soon as reverse gear is engaged, the transmission of the video camera is automatically displayed on the screen.

In addition, on the top right of the display the optical parking system (OPS) appears in a small size.

Rear View Camera



Under „Reverse Camera Guidelines“ you can turn passive guidelines on or off. If the function is turned on, additional settings of the rear view camera can be made when the reverse gear has been engaged.




With the check box „Pause Media Whilst Reverse“, the media playback will be paused when the reverse gear is engaged.

Please note that the volume reduction in reverse gear „Media Volume in CCD“ only works if the feature has been turned off here („OFF“). See also page 24.




Please operate complex settings as a driver generally only if you have parked the car, otherwise the traffic safety is endangered. Otherwise you can not react in time, to avoid occurring danger situations.

Key illumination of the device (only in night driving mode)




Tap on „Display“.



Set the key Illumination brightness by moving the status bar to a desired position.

Note: This is only possible when the light of the vehicle is switched on.




Under „LED Backlight Color“ you can adjust the color of the Key illumination.




You can select a preset color or create a own color set via the RGB controller bars.

Voice (voice control)




Tap on „Voice“.




Tap on „Voice“ to activate the voice control.

BASIC FUNCTIONS




Under „Voice Volume“ you can adjust the volume of the speech output (0-10).

The unit will inform you after the activation of the voice control about the connected devices such as USB sticks or inserted SD cards.




If „Play Bluetooth Status Voice“ is activated, an audible confirmation of the Bluetooth™ connection is issued whenever you connect or disconnect a paired Bluetooth™ device.



Press the button „Mute“ on the device once briefly to start the voice control.


On the screen, possible command examples are shown. Besides the source selection you can also target the title name of e.g. a song on your USB stick.

When you speak no command, the voice control function will be disabled after about 10 seconds (timeout).



Say „Help“ to view a list of possible voice commands.

Operating System



Under „System“ you find information about the system.

- Shell: Version number of the user interface
- OS: Version number of the operating system
- MCU: Version number of the CAN-BUS protocol

Check under www.esxnavi.de if an operating system update is available or ask your retail dealer. Then follow the installation instructions that come with the update.




Do not turn off the car's ignition while updating process of the operating system. Don't run the update while driving.

Calibration of the touchscreen operation


If the touchscreen function is inaccurate you can recalibrate the display. Proceed as follows:



Tap on „System“.



Tap on „Calibration“.




Tap with the included stylus marker on the „+“. Then the „+“ will be moved to another location, then tap again on the „+“ and repeat this process until the calibration is complete. Then confirm the calibration process.

BASIC FUNCTIONS


Audio

You can open the audio settings in the main menu by tapping on „Apps“ and „Audio“ or by pressing the right rotary control (except while DVD/TV playback) on the device.




Tap on one of the control bars to change the sound adjustment.


Note: The change of settings directly influences the „Equalizer“ settings.




Tap on one of the seating positions or on the arrows to align the front and rear speakers.




Tap on „EQ“.




Tap on one of the preset equalizer presets.



Tap on one of the control bars to change the equalizer preset.




Tap on „Advance“ to open the advanced audio settings.



On the left under „Channel Pre-Volume“ you can set the individual volume for each application. Just tap on the arrow icons to change the value upward or downward.

Scroll down the left field to display all applications.



Under „MISC“ you can enable the:

„Fade in“ for very beginning audio track.

„ASL/GALA“ speed-dependent volume adjustment in three stages.


„Media Volume in CCD“ level attenuator, when reverse gear is engaged (low, medium, high). This function is only effective when „Pause Audio playback during reverse travel“ under display (see pg. 31) is set to OFF.

„Reverb“ with 6 DSP presets to change the sound characteristics of the device.



With „Default“ you can restore the respective factory settings.


BASIC FUNCTIONS




Scroll the right field down to see all settings under „MISC“.

Under the section „Loudness“ you can set the bass/treble boost from 0 - 20dB regardless of the equalizer settings.

Note: This can lead to high distortion for the speakers.



Under „Subwoofer“ you can turn on or off the sound output of the RCA output SUBWOOFER and you are able to set its level from -12dB to + 10db.



Unter „Center“ you can turn on or off the sound output of the RCA output CENTER and you are able to set its level from -12dB to + 10db.


In addition, you can switch the device from 5.1 to 4 CH surround sound.



With „Default“ you can restore the respective factory settings.


⚙ Menu assignment

You have the possibility to arrange the main menu or apps menu to your liking.




To change the position of a control panel, press and hold for 5 seconds the regarding panel in the main or apps menu until the dashed lines are visible.

Then hold and slide the control panel to the desired position within the menu.




To occupy a control panel with a new function, touch the control panel for 1-2 sec. to open the edit menu. Tap on „Delete“ to remove the panel.

Tap on „Edit“ to select a new function or application or tap on „Default“ to restore the original factory settings.



Under „Edit“ you can select an application from the list to occupy the current control panel.



You have also the possibility to link a control panel with any compatible software application (.EXE), which must be stored on the available storage locations. Tap on „Browse“ to select the desired application.

Note: To exit the edit menu either press „OK“ or „Cancel.“ To exit the edit mode, tap on the screen (outside of the dashed lines) and the process is complete.


CUSTOM SETTINGS

Wallpaper

You have the possibility to customize the background image to your liking. First, copy the desired wallpaper file to the microSD card or on a USB stick.



Tap on „Apps“.



Tap on „Options“.




Tap at „Wallpaper“ on „Browse“



Select a file by double click.



Tap on „Apply“ to confirm your selection or „Delete“ below to remove the current file.



Alternatively you can set an already opened image as your wallpaper. Tap on „Options“ and select „Set as Wallpaper“.



Under certain circumstances the opening and loading of large images or movie files may take some time to proceed.

⚙️ Bootlogo


You have the possibility to customize the bootlogo (startup logo) to your liking. Please refer to the following instructions.

The screenshot shows the 'Format' dialog box for drive H: (Wechseldatenträger (H:) formatieren). The settings are as follows:

- Speicherkapazität: 7,39 GB
- Dateisystem: FAT32 (Standard)
- Größe der Zuordnungseinheiten: 32 Kilobytes
- Gerätestandards wiederherstellen: (button)
- Volumebezeichnung: X1_UPDATE
- Formatierungsoptionen:
 - Schnellformatierung
 - MS-DOS-Startdiskette erstellen
- Buttons: Starten, Schließen

A yellow arrow points to the 'MS-DOS-Startdiskette erstellen' checkbox.

1. Create an image file which has 800 x 480 pixels in size and has a minimum resolution of 72 dpi.
2. Save this as „LOGO.BMP“ (Windows Bitmap 24-bit).
3. Format an MicroSD card (max. 32GB) with the FAT32 file system. Rename the card as „X1_UPDATE“.




4. Copy the image file from your PC to the SD card. It must be located in no folder.
5. Insert the SD card into the ESX device and restart the device by pressing the reset button. The device now automatically installs the desired boot logo.
6. Remove the SD card and restart the unit by pressing again the reset button.

INFRARED REMOTE

The included remote control allows you to control some basic functions on the device. Point directly with the front of the remote control to the screen of the device. The distance should not be more than 3 meters. If you use the remote control for the first time, you have to remove the safety foil in the battery compartment on the back.

Here is an overview of the basic functions of the remote control, which can be different depending on the currently running application.



- | | |
|--|--|
| 1. Standby. The playback stops and the screen gets dark | 7. Skip to next title |
| 2. Skip to previous title | 8. Volume up |
| 3. Volume down | 9. Mute On/Off |
| 4. Play / Pause | 10. Switch manually to the rear view camera. Press CCD to go back to the previous screen again |
| 5. Open the main menu | |
| 6. Switch manually between the sources:
AV / DAB+ / Radio / Audio Player / TV | |

Note: If the battery (button cell) is discharged, replace it only with a new one of the same type (CR2025). Please do not throw used batteries into household waste, bring them to a dealer that offers a proper disposal, when you purchase a new one.

MULTI-FUNCTION STEERING WHEEL



The device supports a control via the standard multifunction steering wheel. The control buttons are corresponding to the basic function of the device. The operation may vary slightly from car model to car model.


MULTI-FUNCTION DISPLAY



The multi-function display (MFA) between the speedometer displays will also be supported by the device and displays e.g. the directional arrows from the ESX navigation software and RDS information of the radio.

This indicator only works if it is enabled in your car. Ask if necessary your auto repair shop for the activation. The device supports the „MFA +“ and the „MFA comfort“ displays.

LIMITED MEDIA PLAYBACK




For your own and your passengers safety the picture display in DVD/Video/TV/AV applications is limited and the unit will only playback the sound track of the medium while driving.

If you have installed additional screens in the rear, it is possible to keep the video signal visible also during driving.

Note for other Audio/Video outputs:


By using the cable G71-MNV0009 (see installation guide) it is possible to playback audio and video signals on other devices. The media source is always the same, which is played on ESX device.

OPTIONAL REAR VIEW CAMERA



If you have installed an optional rear view camera, the camera image on the screen is automatically shown, when the reverse gear will be engaged (See p.34). This also occurs even when the power is off. After the reverse gear will be disengaged, the device restarts the previously used application or function.

DISPLAY OF OPTICAL PARKING SYSTEM (OPS)



If your vehicle is equipped with the standard parking sensors, an image of the vehicle is shown on the screen and the current parking situation is shown graphically. This function depends on the model and is not supported on all vehicles.

This function depends on the model and may not be supported on every vehicle. To switch to the rear camera view, tap on „CCD“.

TROUBLESHOOTING

If the following troubleshooting tips do not solve the problem and the malfunction persists, please contact an authorized repair or installation service. Do not open the device or attempt to repair it by yourself. This may cause serious damages to the electronic components of the device and in your vehicle or may void the warranty of the device.

Problems	Causes	Remedy
Starting process The device cannot be turned on.	<i>Operator error with the ignition off.</i>	<i>To turn on the device with the ignition off, press and hold the power button of the unit for about 2 seconds. The device automatically switches off after 30 minutes.</i>
	<i>The fuse or a fuse in the vehicle electronics is defective.</i>	<i>Replace the blown fuse with a new fuse of the same type with the same value.</i>
Display Inaccurate or delayed input of touchscreen function.	<i>The touch-screen is not properly calibrated.</i>	<i>Calibrate the touch screen under Apps - Options - System.</i>
	<i>The device opens an application or is currently processing.</i>	<i>Wait until the process is completed.</i>
Screen is black.	<i>The display is disabled.</i>	<i>Tap on the screen.</i>
	<i>The device is in standby mode</i>	<i>Press the left knob on the device.</i>
Sound There is no sound via the sound system of the vehicle audible.	<i>The connection or installation was not done correctly or one of the cables is defective.</i>	<i>Check all connections and replace a possibly damaged cable with a new one.</i>
	<i>One of the audio settings is incorrect or there is an incompatibility with the vehicle sound system.</i>	<i>Check the audio settings under Apps - Audio - Advanced. Go through all settings step by step and test the functions.</i>
	<i>The audio system is not activated properly.</i>	<i>Disconnect the vehicle's battery for at least 30 minutes.</i>
The sound is distorted, overdriven or with strong noises.	<i>The equalizer settings or the volume settings of each application are set unfavorable.</i>	<i>Check the audio settings under Apps - Audio or Advanced. Correct the settings down and test if the sound gets better.</i>

Problems	Causes	Remedy
CD/DVD playback The DVD menu can not be opened.	<i>The disc does not support menus or is plagiarism.</i>	<i>Insert another disc.</i>
The picture quality during playback is insufficient.	<i>Brightness, contrast and color saturation are set too low.</i>	<i>Check the DVD player settings and correct them.</i>
Erroneous or disrupted playback.	<i>The disc is not loaded correctly.</i>	<i>Insert the disc again with the print side up.</i>
	<i>The disc is scratched, broken or deformed.</i>	<i>Insert another disc.</i>
	<i>The disc is not compatible with the device.</i>	<i>Insert another disc.</i>
Optional connected devices (iPod™/TV-Tuner etc.)		
The connected device is not working.	<i>The device is not properly connected or the connection cable is defective.</i>	<i>Check all connections and replace a possibly damaged cable with a new one.</i>
	<i>The devices is not compatible.</i>	<i>If necessary, make a software update or try another device.</i>
USB drive or microSD card is not recognized.	<i>Incorrect storage or data format.</i>	<i>Format the storage with the MS-DOS file system (FAT32).</i>

TROUBLESHOOTING

Problems	Causes	Remedy
Navigation The navigation application will not start.	<i>The software is not compatible with the device.</i>	<i>Check the compatibility of software with Windows CE 6, or get yourself a compatible version.</i>
	<i>The software was not installed on the device properly.</i>	<i>Check the settings under Apps - Options - System and if necessary, correct the navigation software path.</i>
	<i>The license of the installed software or the useful life has expired.</i>	<i>Contact the software supplier.</i>
The device isn't able to find your current location or the route guidance is disturbed.	<i>The included GPS antenna is not or not correctly connected.</i>	<i>Check the GPS antenna connection or get a new one in case of defect.</i>
	<i>You are in an area with weak or no GPS signal, such as in a tunnel or on a remote road.</i>	<i>Continue driving until the GPS signal is available again.</i>
The route guidance does not match with the current road or the map is wrong.	<i>The navigation software is not up to date.</i>	<i>Update the software or contact the software supplier.</i>
The navigation system does not show the shortest way.	<i>The navigation software considers many factors in determining a route, such as the condition of the roads, traffic rules, one-way streets, major roads, etc.</i>	<i>Usually the navigation software selects a route which is a good compromise and most immediate to the goal.</i>
On the displayed map is nothing to see.	<i>The display scale of the map is set too large or too small.</i>	<i>Change the ratio of the display scale, until the map is properly displayed.</i>
	<i>A brief loss of the GPS signal.</i>	<i>Continue driving until the GPS signal is available again.</i>
Radio		
No radio station was found with the automatic station search.	<i>Under PTY a program type is selected, which is not available in the current area.</i>	<i>Select „None“ under PTY. Then, the search for a certain program type is disabled.</i>
	<i>AF or TA is activated.</i>	<i>Disable the AF and TA function and start the search again.</i>
	<i>Antenna system works improperly</i>	<i>Check the plug connection of the original antenna to the radio or check the car antenna system</i>
E-Link		
No connection.	<i>Follow the notes on page 28.</i>	<i>Generally Android should work from version 4.0.3. upwards.</i>
	<i>The Android device is not compatible.</i>	<i>Use another Android device.</i>
No sound.	<i>No Bluetooth connection.</i>	<i>Activate Bluetooth and coupling the device. Note that in an E-LINK coupling, the Bluetooth audio output connection must be enabled.</i>

Problems	Causes	Remedy
Bluetooth/Phone No connection or pairing of the devices.	<i>Bluetooth function of the phone is not enabled.</i>	<i>Enable Bluetooth function in the phone settings.</i>
	<i>Bluetooth enabled but the phone is not visible.</i>	<i>Enable „visible“ in the phone settings.</i>
	<i>The Bluetooth standard of the phone is not compatible.</i>	<i>Use a compatible phone.</i>
	<i>Too many Bluetooth devices are registered in the device.</i>	<i>Delete unused Bluetooth devices from the storage of the device.</i>
Bluetooth connection is too quiet	<i>The preset volume is set too low.</i>	<i>Set the preset volume under Apps - Audio - Advanced - Bluetooth on a higher value.</i>
No Bluetooth audio function.	<i>The Bluetooth audio function is not enabled.</i>	<i>Enable the function in the phone settings.</i>
	<i>The Bluetooth standard of the phone is not compatible.</i>	<i>Use a compatible phone.</i>
The phonebook is not adapted.	<i>The phone does not support the standard.</i>	<i>No remedy, your phone is outdated.</i>
	<i>The phone allows no access to the phone book not via Bluetooth.</i>	<i>Change the settings on the phone (See manual of the device).</i>
Front-/rear camera		
No transmission on the screen.	<i>The camera is not properly connected to the device.</i>	<i>Check the connections for any mistakes.</i>
	<i>The camera was installed improperly.</i>	<i>Check the installation for any mistakes.</i>
	<i>Wrong camera video format or incompatible model.</i>	<i>Replace the camera with a compatible model or refer to the owner's manual of the camera.</i>
The device is turned off, but in reverse gear the camera transmission is shown and the device can not be operated.	<i>The rear camera has priority for safety reasons and also starts the transmission when the device is turned off.</i>	<i>Only after the reverse drive has finished, the device is operable again and can be started.</i>
Driver information display or parking sensors		
No or faulty display.	<i>Your vehicle is not suitably prepared or a CAN bus error exists.</i>	<i>Consult a specialized dealer.</i>
Multifunction steering wheel		
No or faulty operation of the device.	<i>Your vehicle is not suitably prepared or a CAN bus error exists.</i>	<i>Consult a specialized dealer.</i>

Care and Maintenance

This device is equipped with high precision and sensitive technique and should always be treated with caution. Please note the following tips to avoid endangering the warranty and extend the life of the appliance.

- Children under 12 should not operate the device. Keep the device and all accessories away from small children.
- Keep the device and its components dry. The effects of water, liquid or moisture can cause damage to the vehicle, the device itself or injury.
- Keep the device and its components away from excessive heat. High temperatures may shorten the life of appliance of the electrical components.
- Keep the device and its components away from excessive cold. Extreme temperature changes and moisture inside the device may cause the breaking of certain components. Do not to drop the device and avoid violent shocks or excessive shaking.
- Do not use strong chemical cleaners, solvents or water to clean the device. Use a slightly moistened cotton cloth with soft surface.
- Replace a blown fuse only with a new one with the same values. However, before you replace a defective fuse, check at first what is the cause of the short circuit. Start with the power supply cable. If the fuse blows again, a malfunction consists inside the device. In this case you should contact your authorized dealer.

Important note:

In case of loss or damage to the micro SD memory card that contains the navigation software, expires the associated navigation license. In this case, a new software license must be purchased along with a new micro SD memory card.

Legal Notice

- ESX or Audio Design GmbH are in no way affiliated with the Volkswagen AG or any of its subsidiaries or affiliated companies connected to, or is acting on its behalf or with its authorization.
- All registered product names, trade marks and brands are the property of their respective owners.
- This owner's manual was made with the utmost care.
- If you need to dispose the device, be aware that no electronic devices should be deposited in the household waste. Dispose the device in an appropriate recycling facility according to the local waste regulations. Consult if necessary your local authority or dealer.
- Technical changes and errors reserved.

Due to the ongoing development of this device, it is possible that the information in this manual is incomplete or is not matching to the delivery status.

Please visit periodically **www.esxnavi.de** on the internet, to check if additional information and software updates are available.

Customer service

In general, the assembly and installation of the device should be made by a trained and technically skilled specialists.

If you have any problems with operating the device, contact your specialist dealer or the Audio Design Service Department under Tel. **+49 7253 - 94 65 95** or by E-Mail to **navi@esxaudio.de**.

Declaration of Conformity

Distributor:

Audio Design Lautsprecher Vertriebs GmbH
Am Breillingsweg 3, DE-76709 Kronau/Germany

Hereby, Audio Design GmbH declares that the ESX VN720 VO-P6C device is in compliance with the essential, fundamental requirements and other relevant provisions of the following directive:

R&TTE Directive 1999/5/EG

The complete Declaration of Conformity can be found at **www.esxnavi.de/ce**



CAR MEDIA SYSTEMS



ESX Car Media Systems · Audio Design GmbH
Am Breilingsweg 3 · D-76709 Kronau/Germany
Tel. +49 7253 - 9465-0 · Fax +49 7253 - 946510
www.esxnavi.de - www.audiodesign.de

©2017 All Rights Reserved